

縞枯山荘使用頻度チェック表 9月

4台中左 年月日	大便		小便		生ゴミ	廃食油	消費電力	消費時間	温度	状態
	使用人数	使用量(Kg)	使用人数	使用量(L)	投入量(Kg)	投入量(g)	(KW)	(h)	(℃)	
H19.9.1	6	1.5	18	4.5					12	
H19.9.2	14	3.5	38	9.5	0.2				12	
H19.9.3	2	0.5	10	2.5					16	
H19.9.4	6	1.5	20	5					17	↓
H19.9.5	10	2.5	27	6.75					11	良
H19.9.6	8	2	17	4.25	0.2				13	
H19.9.7	7	1.75	23	5.75					11	
H19.9.8	7	1.75	26	6.5					13	
H19.9.9	7	1.75	25	6.25	0.2				11	
H19.9.10	3	0.75	9	2.25					13	
H19.9.11	1	0.25	6	1.5					11	
H19.9.12	0	0	0	0					9	
H19.9.13	6	1.5	20	5					11	
H19.9.14	10	2.5	29	7.25					12	
H19.9.15	2	0.5	11	2.75					15	
H19.9.16	10	2.5	32	8					13	
H19.9.17	7	1.75	25	6.25					13	
H19.9.18	5	1.25	17	4.25	0.3				13	
H19.9.19	4	1	12	3			↓	↓	13	
H19.9.20	0	0	5	1.25					16	
H19.9.21	6	1.5	15	3.75					15	
H19.9.22	5	1.25	25	6.25	0.3				12	
H19.9.23	16	4	47	11.75					11	
H19.9.24	1	0.25	9	2.25					12	
H19.9.25	5	1.25	10	2.5	0.3				13	
H19.9.26	4	1	13	3.25					10	
H19.9.27	5	1.25	16	4					10	
H19.9.28	4	1	26	6.5					10	
H19.9.29	6	1.5	37	9.25					8	
H19.9.30	10	2.5	30	7.5					8	↓
合計	177	44.25	598	149.5	1.5					

4

コントローラー設定値 モーター自動回転時間 5時間毎 ヒーターON30° ヒーターOFF70°
 ↓
 (3/5変更無し)