

縞枯山荘使用頻度チェック表 11月

4台中右	大便		小便		生ゴミ	廃食油	消費電力	消費時間	温度	状態
	年月日	使用人数	使用量(Kg)	使用人数	使用量(L)	投入量(Kg)	投入量(g)	(KW)	(h)	(°C)
H19.11.1	0	0	2	0.5					5	
H19.11.2	0	0	3	0.75					0	
H19.11.3	6	1.5	20	5					-3	
H19.11.4	9	2.25	25	6.25	0.2					↓
H19.11.5	0	0	1	0.25					6	良
H19.11.6	0	0	0	0					2	
H19.11.7	1	0.25	3	0.75					2	
H19.11.8	0	0	0	0					2	
H19.11.9	2	0.5	6	1.5					3	
H19.11.10	4	1	15	3.75					2	
H19.11.11	7	1.75	21	5.25					3	
H19.11.12	0	0	2	0.5					-4	
H19.11.13	0	0	0	0						
H19.11.14	1	0.25	4	1			↓	↓		
H19.11.15	3	0.75	7	1.75						
H19.11.16	0	0	0	0					-3	
H19.11.17	7	1.75	16	4			↓	↓		
H19.11.18	9	2.25	21	5.25					-6	
H19.11.19	2	0.5	4	1			↓	↓		
H19.11.20	0	0	0	0						
H19.11.21	1	0.25	3	0.75						
H19.11.22	3	0.75	8	2						
H19.11.23	7	1.75	18	4.5						
H19.11.24	8	2	14	3.5						
H19.11.25	10	2.5	20	5						
H19.11.26	0	0	5	1.25					1	
H19.11.27	0	0	0	0					-2.5	
H19.11.28	2	0.5	5	1.25					-2.8	
H19.11.29	0	0	0	0					-1	
H19.11.30	2	0.5	6	1.5	0.2				-2.5	↓
合計	84	21	229	57.25	0.4					

温度は朝8時の外気温

コントローラー設定値 モーター自動回転時間 5時間毎 ヒーターON30° ヒーターOFF70°
 ↓
 (3/5変更無し)