

縞枯山荘使用頻度チェック表 11月

4台左中 年月日	大便		小便		生ゴミ	廃食油	消費電力	消費時間	温度	状態
	使用人数	使用量(Kg)	使用人数	使用量(L)	投入量(Kg)	投入量(g)	(KW)	(h)	(°C)	
H19.11.1	0	0	2	0.5					5	
H19.11.2	1	0.25	4	1					0	
H19.11.3	4	1	17	4.25					-3	
H19.11.4	7	1.75	13	3.25	0.2					↓
H19.11.5	1	0.25	3	0.75					6	良
H19.11.6	0	0	0	0					2	
H19.11.7	1	0.25	15	3.75					2	
H19.11.8	1	0.25	3	0.75					2	
H19.11.9	0	0	1	0.25					3	
H19.11.10	4	1	9	2.25					2	
H19.11.11	7	1.75	9	2.25					3	
H19.11.12	1	0.25	5	1.25					-4	
H19.11.13	0	0	0	0						
H19.11.14	0	0	0	0			↓	↓		
H19.11.15	0	0	1	0.25						
H19.11.16	2	0.5	4	1			↓	↓	-3	
H19.11.17	4	1	15	3.75						
H19.11.18	7	1.75	18	4.5			↓	↓	-6	
H19.11.19	0	0	0	0						
H19.11.20	1	0.25	3	0.75						
H19.11.21	0	0	0	0						
H19.11.22	0	0	4	1						
H19.11.23	5	1.25	11	2.75						
H19.11.24	9	2.25	21	5.25						
H19.11.25	7	1.75	19	4.75						
H19.11.26	0	0	0	0					1	
H19.11.27	1	0.25	3	0.75					-2.5	
H19.11.28	0	0	1	0.25					-2.8	
H19.11.29	1	0.25	3	0.75					-1	
H19.11.30	0	0	2	0.5	0.2				-2.5	↓
合計	64	16	186	46.5	0.4					

温度は朝8時の外気温

コントローラー設定値 モーター自動回転時間 5時間毎 ヒーターON30° ヒーターOFF70°
 ↓
 (3/5変更無し)