

縞枯山荘使用頻度チェック表 12月

4台中右 年月日	大便		小便		生ゴミ	廃食油	消費電力	消費時間	温度	状態
	使用人数	使用量(Kg)	使用人数	使用量(L)	投入量(Kg)	投入量(g)	(KW)	(h)	(℃)	
H19.12.1	2	0.5	5	1.25					-3.5	
H19.12.2	6	1.5	11	2.75					-6	
H19.12.3	0	0	2	0.5					-3	
H19.12.4	1	0.25	5	1.25					-8	↓
H19.12.5	0	0	1	0.25					-11	良
H19.12.6	0	0	2	0.5					-5	
H19.12.7	0	0	0	0					-5	
H19.12.8	3	0.75	8	2					-9	
H19.12.9	5	1.25	11	2.75					-9	
H19.12.10	0	0	8	2					-7.5	
H19.12.11	1	0.25	6	1.5					-5	
H19.12.12	0	0	0	0					-4	
H19.12.13	1	0.25	3	0.75					-2	
H19.12.14	0	0	0	0			↓	↓	-8	
H19.12.15	3	0.75	21	5.25					-9	
H19.12.16	7	1.75	17	4.25			↓	↓	-11	
H19.12.17	0	0	7	1.75					-9	
H19.12.18	1	0.25	6	1.5			↓	↓	-9	
H19.12.19	6	1.5	17	4.25			↓	↓	-8	
H19.12.20	0	0	0	0					-10	
H19.12.21	0	0	4	1	0.2				-8	
H19.12.22	9	2.25	26	6.5					-5	
H19.12.23	8	2	21	5.25					-2	
H19.12.24	4	1	19	4.75					-8	
H19.12.25	0	0	2	0.5					-9	
H19.12.26	0	0	1	0.25					-11	
H19.12.27	1	0.25	5	1.25					-9	
H19.12.28	1	0.25	4	1					-9	
H19.12.29	2	0.5	6	1.5					-9	
H19.12.30	5	1.25	17	4.25					-7.5	
H19.12.31	2	0.5	5	1.25					-11	↓
合計	68	17	240	60	0.2					

温度は朝8時の外気温

コントローラー設定値 モーター自動回転時間 5時間毎 ヒーターON30° ヒーターOFF70°
 ↓
 (3/5変更無し)