

縞枯山荘使用頻度チェック表 12月

4台中左 年月日	大便		小便		生ゴミ	廃食油	消費電力	消費時間	温度	状態
	使用人数	使用量(Kg)	使用人数	使用量(L)	投入量(Kg)	投入量(g)	(KW)	(h)	(℃)	
H19.12.1	3	0.75	12	3					-3.5	
H19.12.2	2	0.5	8	2					-6	
H19.12.3	1	0.25	4	1					-3	
H19.12.4	1	0.25	8	2					-8	↓
H19.12.5	0	0	2	0.5					-11	良
H19.12.6	1	0.25	6	1.5					-5	
H19.12.7	1	0.25	8	2					-5	
H19.12.8	4	1	11	2.75	0.2				-9	
H19.12.9	6	1.5	13	3.25					-9	
H19.12.10	1	0.25	4	1					-7.5	
H19.12.11	3	0.75	17	4.25					-5	
H19.12.12	4	1	7	1.75					-4	
H19.12.13	1	0.25	5	1.25					-2	
H19.12.14	1	0.25	7	1.75					-8	
H19.12.15	1	0.25	5	1.25					-9	
H19.12.16	4	1	9	2.25					-11	
H19.12.17	2	0.5	7	1.75					-9	
H19.12.18	2	0.5	5	1.25					-9	
H19.12.19	2	0.5	9	2.25					-8	
H19.12.20	1	0.25	4	1					-10	
H19.12.21	0	0	3	0.75					-8	
H19.12.22	4	1	11	2.75					-5	
H19.12.23	8	2	16	4					-2	
H19.12.24	6	1.5	19	4.75					-8	
H19.12.25	0	0	0	0					-9	
H19.12.26	1	0.25	4	1					-11	
H19.12.27	1	0.25	4	1					-9	
H19.12.28	2	0.5	9	2.25					-9	
H19.12.29	1	0.25	3	0.75					-9	
H19.12.30	3	0.75	11	2.75					-7.5	
H19.12.31	8	2	19	4.75					-11	↓
合計	75	18.75	250	62.5	0.2					

4

コントローラー設定値 モーター自動回転時間 5時間毎 ヒーターON30° ヒーターOFF70°
 ↓
 (3/5変更無し)